


# COMMERCIAL FREEZER INSTRUCTION MANUAL

Model No.: **TGF-9F**  
**TGF-13F**

## FEATURE CHART



How to defrost : Refer page 3.


How to set temperature control : Refer page 4.

Before operating this unit, please read these instructions completely.

## HOW TO INSTALL


### ■ In good ventilation.

- Place the freezer in well ventilated area for better cooling.




### ■ Place the FREEZER on hard and level floor.

- Uneven floor may cause the FREEZER to make noise.



### ■ Put away heat source from the FREEZER.

- High ambient temperature will make cooling efficiency lower.




### ■ Install the FREEZER indoor do not get unit wet.

- This unit is designed for indoor usage only.




### ■ Avoid places that are exposed to smoke.

- The discoloring can occur to the FREEZER.




### ■ Place the FREEZER in an area with low moisture.

- Splashing water or a high moisture area may cause short circuit and make rusting easier.




### ■ Ambient temperature should be below 85°F. Warmer temperature will cause problems with cooling efficiency.



## CLEANING


### ■ Caution

- Unplug the power cord before cleaning.
- Clean the FREEZER periodically.
- Do not use the abrasive cleaners, solvents or polishing agents on plastic parts. These cleansers may cause cracking or discoloring.



### ■ Cleaning the interior and exterior

- Wash it with warm and soapy water and rinse, and dry it.
- Clean the gasket frequently.
- Wash the shelf with water.
- Dewdrops in rainy-season, wipe it with a dry cloth.



### ■ Check points after cleaning

- Check again the FREEZER for safety.
- Do not plug the power cord with wet hands.
- Check the noise or overheating.




### ■ Compressor

- Condenser should be cleaned every 3 months or as needed, unit will not cool properly if dirty.
- Especially, be sure to clean the condenser before reoperating, after a long period of non-operation.

## HOW TO DEFROST

1. Turn the temperature controller to the counterclockwise direction using a minus drive. Refer the diagram. Remove frozen goods.
2. Defrosting usually takes a few hours. To defrost quickly, leave doors open.
3. Never use a knife or other metal instrument to remove ice/frost from the inside of freezer.
4. Place Something under drain hose so water can drain into.
5. Remove plug at bottom inside of unit.
6. After defrosting, the temperature controller dial to the desired position.




**NOTE :** Wait 3 to 5 minutes before restarting if you unplug the freezer, unit may fail to operate properly if restarted too quickly.

## CAUTION

### ■ Ventilation

- Place the FREEZER under proper ventilation
- Keep the cabinet 4" from rear wall.




### ■ Warning


- It is the responsibility of the purchaser in case of followings.
  - Compressor under low voltage
  - Compressor more than 7 feet from plug-in connection.
  - Compressor under unstable voltage
  - Compressor not under 115V/60Hz

### ■ Start-up

- Plug the power cord into the wall outlet.
- The outlet should be only for the FREEZER.
- The temperature controller should be on normal position.
- If disconnected, shut down, wait 5 minutes before re-starting it.



## HOW TO SET TEMPERATURE CONTROL



- The temperature controller is located behind top panel.
- Pull the panel cover, by putting fingers under panel and pull out.
- For colder temperature clock wise warmer temperature counter clock.

## BEFORE REQUESTING SERVICE

| SYMPTOMS   | CAUSES   | SOLUTIONS   |
|--|--|---|
| When the FREEZER does not FREEZES at all.        | <ul style="list-style-type: none"> <li>• When there is a power connection or failure problem.</li> </ul>   | <ul style="list-style-type: none"> <li>• Check the power cord and plug it.</li> </ul>   |
| When the FREEZER does not FREEZE well.           | <ul style="list-style-type: none"> <li>• When the FREEZER is in sunlight or near a heating device.</li> <li>• Too much product.</li> <li>• When the FREEZER door is opened too frequently or left open long.</li> <li>• When the temp. dial is not on the correct position.</li> <li>• When the condenser is dirty.</li> </ul> | <ul style="list-style-type: none"> <li>• Check the installation place.</li> <li>• Check the position of the temp. control dial.</li> <li>• Clean with brush or vacuum.</li> </ul> |
| When there is a severe noise.                    | <ul style="list-style-type: none"> <li>• When the back-side of the FREEZER is close to the wall.</li> </ul>  |   |
| When there are dewdrops on the FREEZER exterior. | <ul style="list-style-type: none"> <li>• High-moisture air can produce dewdrops during the rainy season.</li> </ul>  | <ul style="list-style-type: none"> <li>• Wipe with a dry cloth.</li> </ul>  |
| When there are dewdrops in the FREEZER interior. | <ul style="list-style-type: none"> <li>• When the FREEZER door is opened too frequently or left open long.</li> <li>• When damp food is stored.</li> </ul>   | <ul style="list-style-type: none"> <li>• Keep the door closed to remove dewdrops.</li> </ul>  |
| When the lid does not close tightly.             | <ul style="list-style-type: none"> <li>• Dirty track lid not placed in track.</li> </ul>   | <ul style="list-style-type: none"> <li>• Clean track remove and reinsert lid.</li> </ul>  |

The following points are not malfunctions:

- Water-flowing sound can be heard when the compressor stops.  
This is a sound of REFRIGERANT flowing.

REFRIGERATOR MANUFACTURER  
***Turbo air* MANUFACTURING COMPANY**

ONE YEAR WARRANTY

Turbo air warrants to the original purchaser of every new Turbo air refrigerated unit, the cabinet and all parts thereof, to be free from defects in material or workmanship, under normal use and service, for a period of one(1) year from the date of original installation or 15 months after shipment date from Turbo air, whichever occurs first.

Any parts covered by this warranty that are examined and determined by Turbo air to have been defective within one (1) year of original installation or fifteen (15) months after shipment date from manufacturer, whichever occurs first, shall be repaired or replaced as stated below. Turbo air shall be deemed to have fully complied with its obligation under the foregoing warranties by electing either one of the following procedures, at the sole discretion of Turbo air.

1. Furnishing a replacement part, freight collect, in even exchange for the returned part, freight collect.
2. Receiving the defective part, freight collect; repairing it; and returning it, freight collect.

ADDITIONAL FOUR YEAR COMPRESSOR WARRANTY

In addition to the (1) one year warranty stated above, Turbo air warrants its hermetically and semi-hermetically sealed compressor to be free from defects in both material and workmanship under normal use and service for a period of four (4) additional years from the date of original installation but not to exceed five (5) years and three (3) months after shipment from manufacturer.

Compressors determined by Turbo air have been defective within this extended time period will, at Turbo air's option, be either repaired or replaced with a compressor or compressor parts of similar design and capacity.

The for (4) year extended compressor warranty applies only to hermetically and semi-hermetically sealed parts of the compressor and does not apply to any other parts or components, including, but not limited to, cabinet, paint finish, temperature control, refrigerant, metering device, driers, motor starting equipment, fan assembly any other electrical component, etcetera.

134A(404A) COMPRESSOR WARRANTY

The four year compressor warranty detailed above will be voided if the following procedure is not carefully adhered to:

1. This system contains R134A(404A) refrigerant and polyol ester lubricant. The Polyol ester lubricant has rapid moisture absorbing qualities. If long exposure to the ambient conditions occur, the lubricant must be removed and replaced with new. Listed below are the approved lubricants for the Tecumseh compressors.

- 1 ICI-Emkarate RL 184
- 2 Emery-2927-A
- 3 Mobile Artic 22A

Failure to comply with recommended lubricant specification will void the compressor warranty.

2. Dryer replacement is very important and must be changed when a system is opened for servicing. dryer must be used with XH-9 desiccant.
3. Micron level vacuums must be achieved to insure low moisture levels in the system. 500 microns or lower must be obtained.

### WHAT IS NOT COVERED BY THIS WARRANTY

Turbo air's sole obligation under this warranty is limited to either repair or replacement of parts, subject to the additional limitations below. This warranty neither assumes nor authorizes any person to assume obligations other than expressly covered by this warranty.

1. **WARRANTY IS NOT TRANSFERABLE.** This warranty is not assignable and applies only in favor of the original purchaser/user to whom delivered. ANY SUCH ASSIGNMENT OR TRANSFER SHALL VOID THE WARRANTIES HEREIN MADE AND SHALL VOID ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.
2. **NO CONSEQUENTIAL DAMAGES.** TURBO AIR IS NOT RESPONSIBLE FOR ECONOMIC LOSS; PROFIT LOSS OR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION, LOSSES OR DAMAGES ARISING FROM FOOD OR PRODUCT SPOilage CLAIMS WHETHER OR NOT ON ACCOUNT OF REFRIGERATION FAILURE.
3. **ALTERATION, NEGLIGENCE, ABUSE, MISUSE, ACCIDENT, DAMAGE DURING TRANSIT OR INSTALLATION, FIRE, FLOOD, ACTS OF GOD.** TURBO AIR is not responsible for the repair or replacement of any parts that Turbo Air determines have been subjected after the date of manufacture to alteration, neglect, abuse, misuse, accident, damage during transit or installation, fire, flood, or an Act of God.
4. **NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** THERE ARE NO OTHER WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, EXCEPT THE ONE(1) YEAR WARRANTY AND THE ADDITIONAL FOUR (4) YEAR COMPRESSOR WARRANTY AS DESCRIBED ABOVE. THESE WARRANTIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, INCLUDING IMPLIED WARRANTY AND MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF.
5. **TRANSPORTATION COSTS.** Turbo Air will accept parts covered under this warranty freight collect, provided that shipment has received prior approval. Turbo Air is not responsible for any other transportation costs, but will ship freight collect parts either repaired or replaced under these warranties.
6. **WARRANTY CLAIMS.** All claims should include: model number of the cooler, the serial number of the cabinet, proof of purchase, date of installation, and all pertinent information supporting the existence of the alleged defect. Any action or breach of these warranty provisions must be commenced within one (1) year after that cause of action has accrued.

**Turbo air** REFRIGERATOR MANUFACTURER

1250 Victoria street  
Carson, CA 90746  
U.S.A. & Canada Toll Free 1-800-627-0032  
For Service 1-800-381-7770  
TEL: 310-900-1000  
FAX: 310-900-1077  
[www.turboairinc.com](http://www.turboairinc.com)